



**Aluminum Bases
for the Jpoint, Optima, Delta
& PFI Red Dot Sights.**
(Solid Aluminum)

Model : SB 42
**Sight Base for
Beretta 92 & 96 Model
Auto Pistols**

Notice:

Proper assembly of this product and of any firearm is essential to the proper and safe function of both. It is recommended that this work be performed by a qualified professional gunsmith.

Made In The USA

Aristocrat Products Inc.
1232 E. Edna Place
Covina, CA 91724
(626) 339-4045 Voice
(626) 339-4063 Fax
Info@aristocratproducts.com
www.aristocratproducts.com

Mounting Instructions

1. Remove the existing rear sight and install the dovetail key. The key may require some fitting.
2. Peel the protective paper off of the Battery Pad to expose the adhesive and install in the recess in the sight base.
3. Install the battery into the sight and install the sight on the base.
4. Use alcohol to remove any oil from the threads in the holes in the Dovetail key and from the mounting screws furnished. Apply a small amount of a **REMOVABLE** thread locking compound to the first thread of each screw.
5. Align the base over the dovetail key and the slide. Install the two previously prepared sight mounting screws and tighten firmly with the 2.5 mm Allen key furnished taking care to not damage the plastic sight body.

NOTE: Depending on model of sight used the sight mounting screws can be different!

CAUTION: Make sure that the weapon is not loaded and that safety is in the "ON" position!

