



S- Lever Instructions

**©2022 by E. Arthur Brown Co. Inc. (All Rights Reserved)
4088 County Rd. 40 NW, Garfield, MN 56332 USA
Ph. 320-834-3000, www.eabco.net, sales@eabco.com**

1. Remove the nut from the center of the original friction knob.
2. Unscrew and remove the knurled spacer of the original friction knob
3. Slide the New Spacer onto the threads.
4. Screw the New Nut (S-Lever) onto the threads.
5. Use the S-Lever to tighten or loosen friction of the Bipod.
6. To re-position the lever, lift it and it will disengage and turn.
7. Enjoy your S-Type Canting Bipod much more now with S-Lever!